

InstaShiatsu+ Massage Chair MC-1000

How to Check and Change a Fuse

Note: If you purchased the MC-1000 Massage Chair, please check if you have the extra fuses that were included with your purchase. If you don't have the extra fuses, you will need T5AL250V Cartridge Glass Fuses for replacement.

- 1. Prepare the necessary tools:** You will need a screwdriver (usually a Phillips or flathead) and a flashlight (optional).
- 2. Ensure safety:** Before starting any maintenance or repair work, unplug the chair from the power outlet to avoid electric shock.
- 3. Locate the fuse panel:** The fuse panel on the MC-1000 Massage Chair is typically located at the back of the chair, near the power cord or control panel. It is often covered with a removable panel.
- 4. Remove the fuse panel cover:** Use the appropriate screwdriver to remove the screws holding the fuse panel cover in place. Keep the screws in a safe place for reassembly later.



5. Identify the fuse: Inside the fuse panel, you will see the fuse(s) attached to the fuse holder. Look for a small, cylindrical component with metal ends. This is the fuse.

6. Inspect the fuse: Carefully examine the fuse to check for any signs of damage or a blown fuse. A blown fuse may have a broken connection or a discolored appearance.



7. Replace the fuse: If the fuse is blown or damaged, it needs to be replaced. If you have the extra fuses that came with your chair, take one of the T5AL250V Cartridge Glass Fuses and insert it into the empty fuse holder, aligning the metal ends correctly.

8. Reassemble the fuse panel: Put the fuse panel cover back in place and secure it by tightening the screws with the screwdriver.

9. Plug in the chair: After replacing the fuse and ensuring everything is securely assembled, plug the chair back into the power outlet.

10. Test the chair: Turn on the chair and check if it is functioning properly. If the chair works without any issues, the fuse replacement was successful.

Note: If you encounter any difficulties or the chair still doesn't function correctly after replacing the fuse, it is recommended to contact an authorized maintenance professional or the chair's customer support for further assistance.

By following these instructions, you can effectively check and replace the fuse in your MC-1000 Massage Chair, ensuring its proper functioning.