

Etude Massage Chair

Arm Disassembly & Reassembly

Disassembling Etude Arms:

1. Start by locating the bottom screw positioned under the shoulder air bag. Using an appropriate tool, carefully remove this screw.



2. Lift the foot assembly upwards to access the screw located underneath. Take out this screw using the suitable tool.



3. Locate the three black air hoses connected to the arm. To disconnect them, firmly pull back on each hose until they detach from their respective connectors.



4. Slowly lift up the arm until the harness becomes visible. Unplug the harness by gently disconnecting it from its socket.



Assembling Etude Arms:

1. Position the arm in alignment with the corresponding slots or connectors on the chair's main body.
2. Carefully lower the arm into place, ensuring it fits securely and aligns properly with the screw holes or fastener openings.
3. Plug in the harness by connecting it back into its socket. Ensure a snug and secure connection.
4. Reattach the three black air hoses by inserting them into their respective connectors. Apply firm pressure until they click into place.
5. Lift the foot assembly and insert the screw back into the hole underneath. Tighten the screw securely using the appropriate tool.
6. Finally, locate the bottom screw under the shoulder air bag and insert it back into position. Tighten the screw appropriately with the suitable tool.

Following these steps should help you disassemble and assemble the Etude Arms correctly. Make sure to handle the components with care and refer to any specific instructions provided by the manufacturer for your particular chair model.